



Chopping Boards





Scroll for
building
instructions







15






(18 x)



















(Don't insert half pegs into the outer holes of these panels. They will be hard to remove).


















(When taking this model apart, you can push the half pegs out from the back).






If you get a peg stuck in an outer hole where you can't reach it, see the Building Tips on the Help page of OneKitProjects.com.

























You can push the board halves back together when they break.

